

Replacing a Touchpad – Tech Note

1. Please ensure the mains power is isolated and turned off and then remove the top right hand panel with the 4 screws (fig1). Once removed please disconnect the RJ45 lead from the spa controller labelled either T/P1 or T/P2 (fig 2)



Fig 1



Fig 2

2. Remove the touchpad from the shell by applying pressure from underneath and pushing it away from the spa (fig3). If the touchpad is hard to remove a flat bladed butter knife or screwdriver may be needed to prise underneath the adhesive gasket.
3. Clean any adhesive gasket or silicone left on the spa shell using methylated spirits, eucalyptus oil or some other equivalent product.



Fig 3

4. Feed the cable of replacement touchpad through the hole in the spa shell. Then turn upside down and remove the protective backing from the gasket (fig 4).



Fig 4



Fig 5

5. Line up the touchpad with the shell ensuring that it looks straight. When happy with its placement push touchpad onto shell and apply pressure around all sides of the pad to ensure good adhesion to the shell (fig 5).
6. Reconnect the touchpad cable back to the spa controller to either the T/P1 or T/P2 socket. Replace the top right hand panel and turn the power back onto the spa controller.